

Installation of Ifö Cera toilet 3810-0002

Note that this toilet does not have the same connection to the sewer line as a standard American toilet. The toilet can be fitted if the sewer pipe under the toilet is accessible.

1. After removing the old toilet, remove the flange that is located on the outlet sewer pipe in the floor.
2. If possible, move the sewer line so the center of the sewer pipe is approximately 9" from wall. The final toilet location will then be adjacent to the wall. If moving the pipe is not an option, you can leave it at same location, but the final toilet location will be set off a few inches from the wall.
3. There are two standards in the US for outlet sewer pipe sizing, either 3" or 4".
 - 3.1. If your sewer line is a 4" pipe, simply use a 4" ABS COUPLING piece. The Ifö rubber sleeve (Ifö no. 96292) is then placed onto this.
 - 3.2. If your sewer line is a 3" pipe, then you will need to use an ABS RED COUPLING that reduces from 4" to 3". The Ifö rubber sleeve is then placed onto this.
 - 3.3. Both COUPLING pieces are readily available at any plumbing supply store for a few dollars.
 - 3.4. In both cases, the COUPLING piece should extrude between 2" to 2-3/4" above the finish floor level.
4. Place the Ifö rubber sleeve onto the COUPLING piece.
5. Place the toilet onto the COUPLING aligning the outlet hole in the toilet with the hole in the floor. Squeeze the toilet into place.
6. Attach the toilet to the floor with screws (included in toilet purchase).
7. Attach the water pipe to the 1/2" male coupling on the toilet tank. The threading is Imperial standard so any off-the-shelf hose will work.



ANDERSSON KITCHEN & BATH

www.ifo-usa.com