

Installation of Ifö Cera wall hung toilet 3893

We recommend installing this toilet for new construction or for a remodel of a bathroom. The toilet is attached to the wall so the wall has to be reinforced to be able to handle the weight of both the toilet and the user. The sewer outlet pipe is located inside the wall.

1. Once you decide on the desired height of the toilet seat, refer to the dimensions on the specification sheet to determine the location of the outlet sewer line in wall.
2. Attach the bolts (not provided) to the wall. You will hang the toilet from these bolts. For bolt location, see specification sheet. Be sure to follow load bearing capability requirements as listed in specifications.
3. There are two standards in the US for outlet sewer pipe sizing, either 3" or 4".
 - 3.1. If your sewer line is a 4" pipe, simply use a 4" ABS COUPLING piece. The Ifö rubber sleeve (Ifö no. 96292) is then placed onto this.
 - 3.2. If your sewer line is a 3" pipe, then you will need to use an ABS RED COUPLING that reduces from 4" to 3". The Ifö rubber sleeve is then placed onto this.
 - 3.3. Both COUPLING pieces are readily available at any plumbing supply store for a few dollars.
 - 3.4. In both cases, the COUPLING piece should extrude between 2-9/16" to 2-15/16" outside the finished wall.
4. Place the Ifö rubber sleeve onto the COUPLING piece.
5. Hang the toilet on the bolts while aligning it with the rubber sleeve on the sewer outlet pipe. Squeeze the toilet into place.
6. Attach the nuts to the bolts, and tighten into place.
7. Attach the water pipe to the 1/2" male coupling on the toilet tank. The threading is Imperial standard so any off-the-shelf hose will work.



ANDERSSON KITCHEN & BATH

www.ifo-usa.com